

Cove LED Bunker (Oval Shape) Installation Guide

We strongly recommend that you read this manual carefully before installation.
Installation MUST be carried out by a qualified and licensed electrician.




Replacement
Warranty

Models Parameters

MLXCO34610	10W IP54 Tricolour LED Bunker Oval PIR Motion Sensor White
MLXCO34615	15W IP54 Tricolour LED Bunker Oval PIR Motion Sensor White


Installation Instructions

Step 1




Switch off the mains

Step 2




Remove the diffuser

Step 3




Mark on the desired mounting surface.

Step 4




Drill holes and put the expansion nuts into the hole

Step 5




Mount the housing onto the wall, select desired CCT and connect to power as shown above, Plug power connector between housing and the light fitting.

Step 6




Put the diffuser back on

Step 7



Put the trim back on

Step 8



Switch on the mains

Cove LED Bunker (Oval Shape) Installation Guide

Data Table

Models	Power (W)	PF	CCT (K)	Weight (KG)	Operation Temperature (Degree)	IP	In-rush Current (A)
MLXCO34610	10	≥ 0.5	3000 4000 6500	0.4	+40° -20°	54	5
MLXCO34615	15	≥ 0.5	3000 4000 6500	0.4	+40° -20°	54	5

WARNING

- Installation of product **MUST** follow SAA standards and meet local authority regulations.
- Installation **MUST** be carried out by a qualified and licensed electrician.
- Light **MUST** be earthed.
- Light **MUST** be firmly installed to a flat solid surface, wall or ceiling.
- **DO NOT** immerse any part of the light fitting into water or any form of liquid.
- **DO NOT** look directly into the LED light.
- The warranty is **VOID** if product is not installed according to this installation guide.

2 Year Replacement Warranty

Visit our website for details <https://www.martecaustralia.com.au/warranty-statement/>

