

# Cove LED Bunker (Round Shape) Installation Guide

We strongly recommend that you read this manual carefully before installation.  
Installation MUST be carried out by a qualified and licensed electrician.




Replacement  
Warranty

## Models Parameters

MLXCR34610	10W IP54 Tricolour LED Bunker Round White
MLXCR34615	15W IP54 Tricolour LED Bunker Round White

## Installation Instructions


### Step 1



**OFF**


Switch off the mains

### Step 2




Remove the diffuser

### Step 3




Mark on the desired mounting surface

### Step 4




Drill holes and put the expansion nuts into the hole

### Step 5




Mount the housing onto the wall, select desired CCT and connect to power as shown above, Plug power connector between housing and the light fitting.

### Step 6




Put the diffuser back on

### Step 7



Put the ring (or trim) back on

### Step 8



**ON**

Switch on the mains

# Cove LED Bunker (Round Shape) Installation Guide

Data Table

Models	Power (W)	PF	CCT (K)	Weight (KG)	Operation Temperature (Degree)	IP	In-rush Current (A)
MLXCR34610	10	$\geq 0.5$	3000 4000 6500	0.5	+40° -20°	54	5
MLXCR34615	15	$\geq 0.5$	3000 4000 6500	0.5	+40° -20°	54	5

## WARNING

- Installation of product **MUST** follow SAA standards and meet local authority regulations.
- Installation **MUST** be carried out by a qualified and licensed electrician.
- Light **MUST** be earthed.
- Light **MUST** be firmly installed to a flat solid surface, wall or ceiling.
- **DO NOT** immerse any part of the light fitting into water or any form of liquid.
- **DO NOT** look directly into the LED light.
- The warranty is **VOID** if product is not installed according to this installation guide.

## 2 Year Replacement Warranty

Visit our website for details <https://www.martecaustralia.com.au/warranty-statement/>

