
# Delta LED Wall Lights Installation Guide


We strongly recommend that you read this manual carefully before installation. Installation MUST be carried out by a qualified and licensed electrician.

### **Models Parameters**


MLXD34518W18W LED Wall Light IP54 Tricolour WhiteMLXD34518M18W LED Wall Light IP54 Tricolour Matt Black

### Installation Instructions







Unscrew and remove the mounting bracket.




Replacement Warranty




Mount the bracket on the desired surface using the four screws supplied.




Wire to main as illustrated above.





## Accessories Included





E: sales@martecltd.com.au | P: 02 8778 7500 www.martecaustralia.com.au

# Delta LED Wall Lights Installation Guide

### Data Table

Models	Power (W)	PF	ССТ (К)	Weight (KG)	Operation Temperature (Degree)	IP
MLXD34518W	18	≧0.5	3000 4000 5000		+40° -20°	54
MLXD34518M	18	≧0.5	3000 4000 5000		+40° -20°	54

#### WARNING

- Installation of product **MUST** follow SAA standards and meet local authority regulations.
- Installation **MUST** be carried out by a qualified and licensed electrician.
- Light **MUST** be earthed.
- Light MUST be firmly installed to a flat solid surface, wall or ceiling.
- DO NOT immerse any part of the light fitting into water or any form of liquid.
- **DO NOT** look directly into the LED light.
- The warranty is **VOID** if product is not installed according to this installation guide.

#### 2 Year Replacement Warranty

Visit our website for details https://www.martecaustralia.com.au/warranty-statement/



